
Launchpad
USB
Control Laptop
Network
Internet/Switch
Presenter Laptop
HDMI
[1.5M]
HDMI
[10M]
[SG 10M]
Cam (hackman)
(song only)
Presenter
Timer Laptop
(@WiFi)
Audio
Input 7&8
[SJ3J62-30M-021]
red scaler
(chinese as backup)
HDMI
hdmi out
[Мултивизия]
Projector
[Мултивизия]
Network
SDI
out 1.1
Input 8
[20M]
[25M лилава]снаждане)
Aux1
SDI
[20M]
[TODO]
SDI
out 1.2
[1M]
[TODO]
Text
SDI to HDMI
Converter
HDMI
[3M]
Presenter
Feedback Screen
Network
Audience
Camera 1
SDI
Input 6
[10M]
[TODO]
Input
Video Mixer
Output
Prog
HDMI
[(box)]
Ninja(Recording)
Closeup
Camera
SDI
Input 4
[42M]
[30M + 15 M макари]
(къса при миксера)
[ток]
SDI
Input 3
[3M]
[TODO]
Prog SDI
[(box)]
Teradek(Stream)
HDMI
Input 1
[3M]
[TODO]
Main
Camera
SDI
Input 3
[3M]
[TODO]
Fiber Optic
Converter 2
(silver)
Optical fiber
Camera
(bidirectional)
[макара оптика]
Fiber Optic
Converter1
(white)
Audio
Main Out
(backup)
[2RCA (TODO)]
MultiView SDI
input1
[3m]
[TODO 3m]
MultiView Monitor
Audio
Main Out
[XLR-36M-011 и XLR-10M-013]
chinese scaler
Input
Audio Mixer
Output
Audio
Main Out Amplified
(2 cables - L&R)
[(digger stuff)]
Hall
Mixer/Soundsystem
HDMI
Input 1
[1M]
[TODO]
Audio
Input 9
[MM 3.5 -> XLR]
commercials laptop
[Благо]
Audio Snake
3 free audio cables
(backup audio receiver)
Audio
Input 1
[XLR 1M]
[TODO]
Audio
Input 2
[XLR 1M]
[TODO]
Audio
Input 3
[XLR 1M]]
[TODO]
Audio
Input 4
[XLR 1M]
[TODO]
Audio
Input 5
[XLR 1M]
[TODO]
Speaker Mic
Headset 1
(wireless)
Headset 2
(wireless)
Herald Mic 1
(wireless)
Audience Mic 1
(wireless)
Audience Mic 2
(wireless)
Hall A
SDI
HDMI
VGA
Audio
Network
USB
Optical
Fiber